

Accessories

PRESSURE SUSTAINING VALVE



Sr No	Code	Sutability of filters
1	JSCPSVP2IFL	2" (VHO) filter
2	JSCPSVP2P5IFL	2.5" (VHO) filter
3	JSCPSVP3IFL	3" (VHO) filter
4	JSCPSVP4IFL	4" (VHO, HHO, HEO) filter-
5	JSCPSVMT6I	6" (VHO, HHO, HEO, VEO) filter
6	JSCPSVMT8I	8" (VHO, HHO, HEO, VEO) filter
7	JSCPSVMT10I	10" (VHO, HHO, HEO, VEO) filter

VHO HDPE MANIFOLD




Sr No	Code	Sutability of filters
1	JSCVHO63MMHDPEMF	2" (VHO) filter
2	JSCVHO75MMHDPEMF	2.5" (VHO) filter
3	JSCVHO90MMHDPEMF	3" (VHO) filter
4	JSCVHO110MMHDPEMF	4" (VHO) filter

HHO & HEO HDPE MANIFOLD



Sr No	Code	Sutability of filters
1	JSSH0100MMHDPEMFE	4" (HHO & HEO) filter
2	JSSH0150MMHDPEMFE	6" (HHO & HEO) filter
3	JSSH0200MMHDPEMFE	8" (HHO & HEO) filter
4	JSSH0250MMHDPEMFE	10" (HHO & HEO) filter

HHO & HEO STAND



Sr No	Code	Sutability of filters
1	JSSIAFH0100STC	4" (HHO & HEO) filter
2	JSSIAFH0180STC	6" (HHO & HEO) filter
3	JSSIAFH0300STC	8" (HHO & HEO) filter
4	JSSIAFH0400STC	10" (HHO & HEO) filter

Accessories

SMART CLEAN CONTROLLER



Sr.	Code	Sutability of filters
1	JSCFBC1FDCJB	Single Station Backwash Controller
2	JSCFBC2FDCJB	Two Station Backwash Controller
3	JSCFBC3FDCJB	Three Station Backwash Controller
4		1-10 DC Controller
5		1-3 DC Controller
6		1-10 AC Controller
7		1-3 AC Controller

VHO STAND



Sr.	Code	Sutability of filters
1	JSSIAFH0025STC	2" (VHO) filter
2	JSSIAFH0040STC	2.5" (VHO) filter
3	JSSIAFH0050STC	3" (VHO) filter
4	JSSIAFH0080STC	4" (VHO) filter

SPV DC COIL



Sr.	Code	Sutability of filters
1	JSCSPVDCCOLA	For Sustaining Valve

VEO ELEMENT REMOVE SPANNER



Sr.	Code	Sutability of filters
1	JSCVEOELEOP-TOL	Element opening tool (VEO)

SCREEN REMOVING TOOL



Sr.	Code	Sutability of filters
1	TOOLF SR	Screen Removing Tool (HHO & HEO)

ELEMENT OPENING TOOL



Sr.	Code	Sutability of filters
1	JSCHOELEOP-TOL	Element opening tool (HHO & HEO)